

external view of 300BSEi to show location of standoffs, standoff screws and grommets



key

- A** = M3x20mm standoff + M3 x 10/countersunk screw (4 off)
- B** = M3x20mm standoff + M3 x 10/countersunk screw (4 off) 300BSEi only
- C** = M3x20mm standoff + M3 x 12 black pozi-drive screw (6 off)
- D** = M3x25mm standoff + M3 x 12 black pozi-drive screw (2 off)
- E** = M3x15mm standoff + M3 x 12 black pozi-drive screw (4 off)
- F** = large grommet (4 off)
- G** = small grommet (2 off)

a useful tool for fitting the front plate

